




# Lenovo IdeaTab A2109 Digital Board Replacement

Replace the digital board in your Lenovo IdeaTab A2109.

Written By: Brian



## INTRODUCTION

Use this guide to replace the digital board.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Tweezers](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Digital Board



- Look at the back of the tablet and locate the speakers on top of the rear cover.
- There is a smaller plastic cover that runs across the top of the device.
- Wedge the blue opening tool, under the middle of the cover as shown, then push up and the cover will pop off.

## Step 2



- Remove the following two screws:
  - M3.0 x 3.0 mm #00 phillips screws (black)




## Step 3





- Once it is unscrewed, remove the rear cover
  - This may take a little force to get off but with enough force it should pop right off
- Use a blue opening tool to pry it open
  - Slide the tool to one corner then grab another tool and slide it to the opposite corner
- Pull the cover up and it will come off

## Step 4




- Use the tweezer tool to flip up the three small plastic locks attached to the digital board.
- Then, slide newly exposed ribbons out.

## Step 5



- Remove the following two screws:
  - M5.3 x 1.75 mm #00 phillips screws (silver)

## Step 6



- Once it is unscrewed, use the tweezer tool to pull the digital board straight out.

To reassemble your device, follow these instructions in reverse order.

